

Disclaimer

This Region 4 Backcountry Flying Guide is intended to provide useful VFR flight information for the USFS backcountry airstrips and airstrips used by Forest Service pilots.

The Intermountain Region (Region 4) and the US Forest Service assume no responsibility for incomplete or inaccurate information contained in this this backcountry flying guide.

Pilots are reminded that it is their responsibility to check FAA NOTAMS, the Aeronautical Information Manual (AIM), FAA flight service stations, and current airport conditions from the airport owner or manager before conducting any flight operations.

Category 4 sites include mountain/remote airstrips, off airport take-off/landing sites, waterways, and helibases/helispots (incident or resource) not associated with Category 1, 2 or 3 locations. Category 3 may also meet the definition of Category 4 due to complexities associated with the site such as landing surface, airstrip length and width, approach/departure obstacles, etc. Approach and departure from Category 4 takeoff/landing locations require non-standard traffic patterns due to hazardous terrain and multiple obstacles. Category 4 takeoff/landing locations may be depicted by a magenta circle on FAA Sectional Aeronautical Chart and World Aeronautical Charts as USFS, Restricted, or Private Airstrips. Pilots may be required to obtain use authorization from the appropriate Administrating Agency.

All USFS strips that are owned and maintained are Category IV airstrips

Category 4 Pilot Carding

Fixed-wing pilots must have a Category 4 airstrip endorsement on their Pilot Qualification Card and must meet specific agency currency requirements for remote/backcountry operations.

RELATIVE HAZARD INDEX

"No part or use of the Relative Hazard Index (RHI) authored by Galen L. Hanselman, of Q.E.I Publishing Inc., will be utilized by any other government agency or entity other than the US Forest Service. Mr. Hanselman has provided written authorization to utilize the RHI information for use by the US FOREST SERVICE ONLY. The information has a copyright of 1994 by Mr. Galen L. Hanselman. Anyone desiring the use of this information outside of the US Forest Service must obtain written permission from the publisher."

	Relative Hazard IndexAirport Environment	1	7 RH	I
A/D	Approach / DepartureRunway Surface Hazards	09 AE	07 A/D	01 RSH

The RHI is a relative composite number with which the current known physical hazards of airstrips can be compared. The purpose of the RHI number is to give the pilot as much information about the airstrip as possible. Short final is not the place to realize that you are in over your head.

As is true throughout aviation, the pilot has sole responsibility for his/her safety. The RHI is simply one of several tools which a pilot may use to factor in his go/no go decision.

RHI DERIVATION

The RHI is derived from three composite numbers: Airport Environment (AE), Approach/Departure Environment (A/D), and Runway Surface Hazards (RSH).

RHI WORKSHEET

Airport Name:	
AIRPORT ENVIRONME	ENT (AE)
RUNWAY LENGTH - Choose one:	5 4 3 2 1
Su	ıbtotal
AIRPORT ELEVATION - Choose one: >7000' 6000' - 7000' 5000' - 6000' 4000' - 5000' 3000' - 4000'	5 4 3 2 1
Su	ıbtotal
MOUNTAIN PROXIMITY - Choose one: (mountains defined in terrain exceeding 1000' a <1 mi. 1 mi 3 mi. 3 mi 5 mi.	5 3 1
Su	ıbtotal:
AIRPORT ENVIRONMENT TOTAL (AE)	

APPROACH/DEPARTURE ENVIRONMENT (A/D)

APPROACH - Choose all that apply: abrupt turn required on final non-standard pattern required airstrip not visible on 1/2 mile final >50' obstacle on final approach over water no go around from flare RWY selection dictated by terrain, not wind	5 3 4 4 3 2
DEPARTURE - Choose all that apply: abrupt turn required on departure end of runway not visible departure over abrupt dropoff RWY selection dictated by terrain, not wind	5 1 2 2
APPROACH/DEPARTURE SUBTOTAL (A/D)	
RUNWAY SURFACE HAZARDS (RSH) (Choose all that apply) no runway markings no windsock overgrown grass loose gravel soft sand mud deep erosion/water on runway deterioration due to rodents or large animals dog leg bumps (1 pt. for each bump) dips (1 pt. for each dip) adverse gradient (uphill for takeoff, downhill landing) other	2 1 2 2 2 1 1 1 2 1 1 2 1 1 1 2 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
RUNWAY SURFACE HAZARDS (RSH) TOTAL	
RHI = AE + A/D + RSH = TOTAL OF * NUMBERS	

SURVIVAL

KEY SURVIVAL ACTIONS

- Make sure your ELT is on and working.
- Evaluate your location dangers: fire, sliding, rock fall, avalanche, terrain, weather, etc.
- Stay near the aircraft if at all possible for warmth, shelter and signaling materials. Your aircraft can fulfill most of your basic needs if you improvise. Think basic: shelter (cover), warmth (fabric), tools (metal), maps, newspaper, engine cover and plastic tarps all make excellent emergency bedding.
- Wings, rudders, etc., all may be used to make a shelter. Keep this shelter as small as possible to lessen the area your body must heat. Insulate shelters with branches, bark, tarps, maps, etc. Use anything to keep the rain from getting inside your shelter. Body heat loss is energy loss.
- Signal for help. Do not neglect your aircraft radio. It may still be operational. Turn on squelch and volume and key the mike. If your radio works, listen on a local or ATC frequency. When you hear radio traffic, transmit "Mayday--Mayday". If both your ELT and radio are working, you will hear the ELT signal when listening on 121.5. It may be necessary to turn the ELT off when transmitting or listening on 121.5. Don't forget to turn the ELT back on! If you do not hear any transmissions, transmit in the blind on this frequency. Limit your transmissions to about one every fifteen minutes. Transmitting places considerably more drain on the battery than receiving.
- Aircraft should be made visible from the air if possible. Clear brush, cut trees, etc., and be prepared to make signals (mirror, smoke, flares, colored items, etc.) as aircraft approach your area. Keep a signal mirror handy if the sun is shining.
- Use anything available that is in contrast to the color of your surroundings to create a mark (SOS, X,) that will be visible from the air.
- Build a fire for both warmth and signaling, if possible. Don't forget that the aircraft gasoline is a valuable resource in starting a fire when only wet wood is available. Caution must be used when using gasoline. Soak or pour gasoline on the wood but be sure the

- container is out of reach when lighting. When collecting firewood gather enough to keep the fire going for an extended period of time. Keep the fire burning at all times.
- In cold weather, insulation and upholstery from the aircraft, make excellent material for boot covers, sleeping bags, mittens, hats and ground insulation. Sew them together with salvaged aircraft wire or use tape. Put plastic side out for better protection
- If water is not readily available melt snow or ice in improvised pot, or collect dew either from aircraft surfaces or by placing a sheet of plastic flat on the ground. If it is raining, place plastic sheet in ground depression to collect water.

SURVIVAL KIT

- Survival Compass (learn how to use it)
- Tool kit (small, light weight)
- First aid kit
- Food (non-perishable, light weight)
- Water (consider terrain along route when determining how much)
- Water purification tablets or filters
- Disposable space blankets
- Saw (folding or rope)
- Matches (waterproof) & fire starter
- Signaling devices--(flares, mirror, strobe light)
- Knife
- 50' 1/8" nylon rope
- Garbage bags
- Fish hooks, sinkers and line
- Can opener, steel cup
- Seasonal clothing
- Sleeping bag
- Seal smaller items in a container suitable to heat & store water, such as a 1-gallon coffee can.
- Survival manual.

MOUNTAIN FLYING TIPS

Prior to flying into the backcountry, consider the following:

GENERAL

- Do not consider flying the mountain country until you are proficient in slow flight. <u>Instruction from an experienced mountain</u> <u>flying instructor is strongly recommended.</u>
- Before flying into mountainous areas, practice short field landings, power-on, upwind, downwind and crosswind. Be sure you can land within a fifty foot spot every time.
- Know your aircraft. Most airports in the Idaho mountains are substandard in length and width and have an associated high density altitude. It takes considerable experience to handle an aircraft in the mountain environment.
- Keep your aircraft weight as light as possible.
- Know your destination and alternate airports. Consult with experienced mountain pilots for specifics such as altitude, length, conditions and approach and departure procedures for your intended airport. At many of the airports a go-around is not possible once you have committed to land.
- Check the weather frequently and stay out of marginal or bad weather. Mountain weather changes rapidly and unexpectedly.
- Plan your flight to arrive in the early morning hours. As a rule, the air begins to deteriorate around 10:00 a.m., grows steadily worse until about 4:00 p.m., and then gradually improves until dark.
- Stay out of the mountains if the wind is over 25 knots.
- Route your trip over valleys whenever possible and study your charts thoroughly. Watch your compass heading to avoid getting lost.
- Know your position and announce frequently on 122.9 mhz to let other pilots in the area know your position and your intentions.
 Example: "9438M over Warm Lake at 9500 for Johnson Creek."
- Fly to the right side of the canyon if possible.
- Turn on your landing lights during arrival and departure.

- Maintain a minimum of 2000' AGL while flying over the backcountry. Remember others are in the mountains to enjoy a wilderness experience.
- Approach all ridges at an angle so that you can turn away if you encounter a downdraft. After crossing the ridge, head directly away from it.
- Expect the wind to be changing constantly in the mountains. Do
 not rely on the cloud shadows for wind direction. If you are unable to gain altitude on one side of the canyon, try the other side.
 If there is no improvement there, fly the center. But do not, under
 any circumstance, fly up a canyon or valley without sufficient altitude and room to turn around. The grade of the canyon may
 climb faster than your aircraft.
- Maintain flying speed in downdrafts.
- Remember you will not have a horizon to check your aircraft attitude during descent in the mountains. Watch your airspeed and cross-check your instruments.
- Caution: traffic pattern terrain clearance is not standard at many mountain airports.
- Remember that mountain airports are subject to ongoing damage by weather, livestock, wild animals, and aircraft operations. Most of them are unfenced and wild animals and livestock may be on runways.
- Above all, FLY THE AIRCRAFT EVERY SECOND, DO NOT LET IT FLY YOU.

Under ordinary circumstances you can expect the wind to be blowing upstream in the late morning and afternoon as the air heats up, and downstream in the evening as it cools. The wind is affected by the topography. With a little analysis you can tell where the updrafts and downdrafts are likely to be. As a general rule, air follows the contour of the land. Use the updrafts to help you gain altitude.

Be sure to leave your itinerary and emergency contact phone numbers with someone. Instruct them to act IMMEDIATELY in the event you have not made contact by the identified time.

Always remember you are flying in a sparsely populated area. If you have an accident, it may be a long time before anyone knows about it. You may be landing on airports where there is no one to help you in case of trouble and it can be a long walk out. Do not take chances. Equip yourself with proper clothing and at least minimum survival equipment on any flight into mountainous areas.

Make sure your ELT and Personal Locator Beacon are in good working condition.

LANDINGS

Safety of flight dictates that each pilot transmit in-the-blind on the appropriate frequency whenever approaching or departing a non-unicom equipped airport to advise other aircraft of your location and intentions.

You cannot maintain visual contact with the runway at many of the backcountry airports during the approach. This situation will make it mandatory that you know the location and intentions of all other airport traffic. These airports receive considerable use when forest fires or similar emergency conditions exist. Make periodic position reports on 122.9 while flying over the backcountry, giving your location, altitude and destination. This will keep other pilots advised of your intentions and will greatly aid in any rescue effort that may be necessary.

- Terrain, runway gradient, and wind direction usually dictates landing direction. However there are exceptions. Consult the airport directory for the preferred runway for landing. Maintain the recommended approach speed with power (see pilot's operating handbook). Retract the flaps immediately after contact to permit the aircraft weight to settle on the gear to increase braking effective.
- If you find turbulent air when you descend into the canyons, return home. Turbulent air has no respect for you, regardless of your experience or ability.
- After landing, park your aircraft well clear of the useable runway surface.
- Check the ELT on 121.5 Mhz before leaving aircraft.
- Few backcountry airstrips have telephone or cellular phone ser-

vice. Pilots must have other means such as satellite service to close or open flight plans.

TAKEOFFS

- Temperature increases density altitude (that altitude the aircraft thinks it is at) so a 5000' airport elevation can be well above 8000' density altitude on a hot day. You should compute your takeoff roll using your pilots operating handbook or other published guidelines. Also, compute your rate-of-climb to ensure you can achieve and maintain terrain clearance. If in doubt, do not take off.
- Use common sense on takeoffs. If the air is turbulent, weather is marginal, or you have a tailwind, wait until conditions improve. Remember: most of these airports are not long enough to abort a takeoff attempt once airborne. Let the aircraft use as much runway as it needs, then it will be flying when it leaves the ground. Do not force the aircraft off the ground, be sure you gain adequate flying speed.
- You can shorten the takeoff distance by making your turn at the end of the runway at a good, fast taxi speed, open the throttle as the aircraft swings around to line up with the runway. Practice the maneuver with an instructor on a standard airport.

COMMON COURTESY


Wilderness areas and airstrips are particularly sensitive to human impact. The wilderness airports are intended to serve as access portals for wilderness-dependent activities such as hunting, fishing, rafting, backpacking, etc.

- Be considerate of other users
- No noisy activities
- Minimize practice landings and takeoffs
- If you fly it in, fly it out


Remember: everyone likes a good neighbor!

CAUTION: Snowmobiles may be using backcountry airports during winter months.

WIND COMPONENT



 ${\tt CROSSWIND\ COMPONENT-KNOTS}$



Example:

The diagonal line shows that 230% must be added for a temperature of 100° and a pressure altitude of 6,000 feet.

Therefore, if your standard temperature sea level take-off distance normally requires 1,000 feet of runway in order to climb to 50 feet, it would become 3,300 feet under the conditions shown.

In addition, the rate of climb would be decreased 76%. Therefore, if your normal sea level rate of climb is 500 feet per minute, it would become 120 feet per minute.

STARTED SPECIALIST INITIALS		7. CRUISING					15. NUMBER	ABOARD		ent flight rules in Section 901 of the ting practice. See	ARRIVAL
TIME STARTED		6. DEPARTURE TIME) ACTUAL (Z)				HOME BASE			erate under instrum for each violation (seed as a good opera	_ FSS ON ARRIVAL
U VNR	Ī	6. DEPA	PROPOSED (Z)				NUMBER & AIRCRAFT H		PTIONAL)	FR flight plan to ope not to exceed \$1,000 nt plan is recommend	
(1)(0)	STOPOVER	5. DEPARTURE POINT					14. PILOTS NAME, ADDRESS & TELEPHONE NUMBER & AIRCRAFT HOME BASE		17. DESTINATION CONTACT/TELEPHONE (OPTIONAL)	CIVIL AIRCRAFT PILOTS. FAR Part 91 requires you file an IFR flight plan to operate under instrument flight rules in controlled airspace. Failure to file could result in a civil penalty not to exceed \$1,000 for each violation (Section 901 of the Federal Aviation Act of 1958, as amended). Filing of a VFR flight plan is recommended as a good operating practice. See also Part 99 for requirements concerning DVFR flight plans.	PLAN WITH
Y) 🗆 PIU	_	4. TRUE	AIKSPEED		11. REMARKS		14. PILOT'S NAI		17, DESTINATION	LOTS. FAR Parl Failure to file cot of 1958, as ame ements concerni	R FLIGHT F
(FAA USE ONLY) PILOT BRIEFING		3. AIRCRAFT TYPE /			10. EST. TIME ENROUTE	RS MINUTES	AIRPORT(S)			VIL AIRCRAFT PI ontrolled airspace. ederal Aviation Act so Part 99 for requir	CLOSE VFR FLIGHT PLAN WITH
	z	3. AIR	5		10. E	HOURS	13. ALTERNATE AIRPORT(S)			0828	
U.S. DEPARTMENT OF TRANSPORTATION FEDERAL AVIATION ADMINISTRATION	FLIGHT PLAN	2. AIRCRAFT		пент	9. DESTINATION (Name of airport			MINUTES		AIRCRAFT	33-1 (8-82) sion (Adobe)
U.S. DEPART FEDERAL A	Ā	1. TYPE 2	VFR IFR DVFR	8. ROUTE OF FLIGHT	9. DESTINATIO	and city)	12. FUEL ON BOARD	HOURS		16. COLOR OF AIRCRAFT	FAA Form 7233-1 (8-82) Electronic Version (Adobe)

THIS CHART FOR PLANNING ONLY, IT IS NOT LIMITING

DHC-6 Rate of Climb - One Engine Inop.
Flaps = 10°. Intake Deflectors = Up. Prop = 96%. Torque = Max
Cont.


cont.									
Maximu	Maximum weight allowable to achieve a 200'/Nm 2nd segment climb (=								
264 fpm VVI @ 80 KTAS)									
Tempe	erature			Pres	sure Alt	itude			
°F	°	2000	3000	4000	5000	6000	7000	8000	
68	20		12,500	12,400	11,900	11,700	11,100	10,700	
71.6	22		12,500	12,300	12,000	11,500	11,000	10,600	
75.2	24		12,500	12,100	11,700	11,400	10,900	10,500	
78.8	26		12,500	12,000	11,500	11,200	10,700	10,300	
82.4	28	12,500	12,400	11,900	11,400	11,000	10,600	10,200	
86	30	12,500	12,300	11,800	11,200	10,800	10,300	10,000	
89.6	32	12,500	12,000	11,500	11,000	10,600	10,200	9,800	
93.2	34	12,300	11,800	11,300	10,900	10,600	10,000	9,600	
96.8	36	11,900	11,500	11,200	10,700	10,400	9,900		
100.4	38	11,700	11,200	11,000	10,600	10,100	(Not C	harted)	
104	40	11,500	11,100	10,900	10,500				

Max	Maximum weight allowable to hold level flight (= 0 fpm VVI @ 80 KTAS)								
Tempe	erature			Pres	sure Alt	itude			
°F	C°	2000	3000	4000	5000	6000	7000	8000	
68	20								
71.6	22								
75.2	24								
78.8	26								
82.4	28			(MTC	OGW)				
86	30							12,500	
89.6	32							12,100	
93.2	34						12,500	11,800	
96.8	36						12,200		
100.4	38					12,500	(Not C	harted)	
104	40				12,500				



Quick Reference Guide

For Radio Firmware: 2.x.x



- 1. SQUELCH INDICATORS (LED) Lights when signal received (Top: Main, Bottom: Guard).
 2. CHANNEL DISPLAY (2 Line x 24 char) Shows channel parameters (Top: Main, Bottom: Guard).
 3. MAIN (Rotary+Switch) Power ON/OFF and Main channel volume control.
 4. GUARD (Rotary) Guard channel volume control.
 5. SQUELCH DEFEAT (Push button) Press to open squelch (in analog modes of operation).
 6. MN/GD (Toggle Switch) Selects active channel (Main or Guard) for transmit and edit functions.
 7. G1/G1 (Toggle Switch) Selects active Guard memory (G1 or G2) for transmit and edit functions.
 8. HI/LO (Toggle Switch) Selects Transmit Power: High (10w) or Low (1w).
 9. KEYLOADER PTT keying is provided via the back connector, and is part of a correctly installed system.
 10. KEYPAD (12 Keys) Control radio functions, 3 command levels as follows:

	Command/Operator Level 1: Press the 'Cmd' key							
Cmd	Function	Edit Keys	ок	Exit				
1 CHAN	SELECT MEMORY	O 9 ENTER CHANNEL MEMORY (001 to 230)	# ENTER	* ESC				
2	DISPLAY BRIGHTER							
3 MODE	EDIT OPERATING MODE	3 2 8 STEP UP/DOWN THROUGH OPERATING MODES	# ENTER	* ESC				
4	SCROLL MEMORY DOWN	SCROLL DOWN THROUGH THE PROGRAMMED MEMORY POSITIONS						
5 SCAN	SCAN ON/OFF	5 SCAN OR ESC STOP SCAN						
6	SCROLL MEMORY UP	SCROLL UP THROUGH THE PROGRAMMED MEMORY POSITIONS						
7 FREQ	EDIT FREQUENCY	0 9 SOL SELECT FREQUENCY THEN BYTER TX FOLLOWS RX.	# ENTER	* ESC				
8	DISPLAY DIMMER							
9 sqL	EDIT SQUELCH MODE	9 2 8 STEP UP/DOWN THROUGH SQUELCH MODES. Tx FOLLOWS Rx.	# ENTER	* ESC				
	EDIT SQUELCH VALUE	STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & NAC HEX STEP UP/ DOWN THROUGH: TONES, CODES, TG & N	# ENTER	* ESC				
0 PROG	GO TO NEXT LEVEL	GO TO THE NEXT HIGHER COMMAND LEVEL						
# ENTER	n/u							
* ESC	n/u							

	Command/Operator Level 2: Press + the 'Cmnd' key							
Cmnd	Function	Edit Keys	ОК	Exit				
1 CHAN	CREATE/EDIT CHANNEL	O S SELECT CHANNEL MEMORY TO EDIT THEN EDIT: SCAN LIST (L2-5), TEXT DESCRIPTION (L2-6) OPERATING MODE (L1-3), FREQUENCY (L1-7), & SQUELCH (L1-9)	# ENTER	* ESC				
2	COPY GUARD TO MAIN	COPY CHANNEL PARAMETERS FROM GUARD TO MAIN (default disabled)						
3 MODE	LOCK KEYPAD	* UNLOCK KEYPAD						
4	n/u							
5 SCAN	EDIT SCAN LISTS	Step up/down through available scan lists On toggle enable/disable for scan (bar over digit = disabled)	# ENTER	* ESC				
(6)	EDIT TEXT DESCRIPTION	STEP THROUGH CHARACTER GROUPS (A, a, 0, BLANK) B STEP/SCROLL UP/DN THROUGH CHARACTERS IN SELECTED GROUP D D D D D D D D D D D D D D D D D D D	# ENTER	* ESC				
7 FREQ	CREATE SHADOW	THEN EDIT: TEXT (L2-6), MODE (L1-4), SQUELCH (L1-9)	# ENTER	* ESC				
8	COPY MAIN TO GUARD	COPY CHANNEL PARAMETERS FROM MAIN TO GUARD (default disabled)						
9 SQL	SET UNIT ID	0 9 9000 TO 90 UNIT ID VALUE FROM: 0 TO 9999999	# ENTER	* ESC				
0 PROG	GO TO NEXT LEVEL	GO TO THE NEXT HIGHER COMMAND LEVEL						
# ENTER	n/u							
* ESC	GO TO PREVIOUS LEVEL	GO TO THE PREVIOUS COMMAND LEVEL						

	Command/Operator Level 3: Press Press Command							
Cmnd	Function	Edit Keys	ок	Exit				
1 CHAN	SET BOOT CHANNEL	1 B STEP UP/DOWN THROUGH BOOT MEMORY OPTIONS	# ENTER	* ESC				
2	n/u							
MODE 3	SET NUMERIC EDIT MODE	3 1 1 1 TOGGLE HEX/DECIMAL EDIT MODE (FOR T.G & NAC)	# ENTER	* ESC				
4	DISPLAY FIRMWARE REV.	1 1 1 1 TOGGLE MAIN/BOOT FIRMWARE RELEASE INFORMATION	# ENTER	* ESC				
5 scan	SET SCAN PARAMETERS	THEN SELECT REVERT MODE THEN SELECT REVERT MODE THEN SELECT REVERT MODE THEN SELECT REVERT MODE	# ENTER	* ESC				
6	SET PTT TIMER	(30, 60, 90 SEC)	# ENTER	* ESC				
7 FREQ	SET SIDETONE AUDIO	O 9 SOL SET SIDETONE LEVEL (00 TO 85)	# ENTER	* ESC				
8	PC COMMUNICATION	MUST BE CONNECTED TO A PC RUNNING TDP-136 SOFTWARE		* ESC				
9 sqL	SHOW SQUELCH VALUES	9 1 B TOGGLE RX/TX SQUELCH PARAMETER DISPLAY	# ENTER	* ESC				
0 PROG	n/u							
# ENTER	n/u							
* ESC	GO TO PREVIOUS LEVEL	GO TO THE PREVIOUS COMMAND LEVEL						


- NOTES:

 The channel being edited is determined by the position of the front panel switches MN/GD and G1/G2.

 Current command level is shown at 4" character on bottom row.

 Levels 2&3 are time limited, the unit will return to level 1 if no activity in 5 seconds.

TiL 3342C





VOR **FREQ** RAD NM BOI 113.3 053 47.5

NAV AIDS: NO LIGHTS: NO ATTENDED: FUEL: NO NO NO FBO: TIEDOWNS:

(1) REPEATER: SWANHOLM (37) RX FREQ: 172.200 TX FREQ: 165.4125 (131.8)

(2) REPEATER: TRINITY (43) RX FREQ: 172.200 TX FREQ: 165.4125 (179.9)

MANAGER: 208-334-8775


STATE OPERATED


REMARKS: LAND RUNWAY 34. TAKEOFF RUNWAY 16. LANDING OR TAKEOFF WITH UNFAVORABLE WINDS NOT RECOMMENDED. CHECK AIRCRAFT PERFORMANCE FOR HIGH DENSITY ALTITUDE. GO-AROUNDS FROM FINAL NOT POSSIBLE DUE TO HIGH TERRAIN. STEEP ENCLOSING TERRAIN. RECOMMEND USE ONLY BY MOUNTAIN PROFICIENT PILOTS. NO WINTER MAINTENANCE. DEPART WITH A RIGHT TURNOUT DOWN THE BOISE RIVER. CAUTION: DUE TO CLOSE PROXIMITY OF GREENE AIRPORT MONITOR-ANNOUNCE INTENTIONS ON 122.9


ATLANTA


ATLANTA


55H
















REMARKS: RECOMMENDED LAND RWY 19. DEPART RWY 01. CHECK AIRCRAFT PERFORMANCE FOR HIGH DENSITY ALTITUDE. RWYWAY MAY NOT BE VISIBLE FROM ALL PARTS OF TRAFFIC PATTERN. STEEP ENCLOSING TERRAIN. RUNWAY SUBJECT TO ONGOING RODENT DAMAGE. NO WINTER MAINTENANCE. AIRCRAFT USE SIDES OF STRIP DURING SKI OPERATIONS.

BIG CREEK

U60







REMARKS: NORMALLY LAND RWY 05, DEPART RWY 23. AIRPORT IS LOCATED IN A HIGH MOUNTAIN VALLEY SURROUNDED BY HIGH TERRAIN. VERY HIGH DENSITY ALTITUDES IN SUMMER. AIRCRAFT TIEDOWN AREA IS ROUGH. NO WINTER MAINTENANCE. WHITE ROCK BOUNDARY MARKERS.


BRUCE MEADOWS


STANLEY

U63












TAKEOFF RWY 07. RWY 07-25 AND RWY 15-33 THRESHOLDS MARKED WITH YELLOW PILED ROCK BOUNDARY MARKERS. CHECK AIRCRAFT PERFORMANCE FOR HIGH DENSITY ALTITUDE. RISING TERRAIN AND POTENTIAL DOWNDRAFTS WEST OF THE AIRPORT. RUNWAYS AND TIEDOWNS SUBJECT TO RODENT DAM.


CHAMBERLAIN BASIN USFS U79














LOCATION: 3 MILE SW OF DIXIE

FOREST: NEZ PERCE NATIONAL FOREST

VOR FREQ RAD NM 112.6 55.0 DNJ 014 NAV AIDS: NO LIGHTS: NO ATTENDED: NO

(1) REPEATER: IRON MOUNTAIN (93) RX FREQ: 168.6750 TX FREQ: 169.9500 (110.9)

FUEL: NO FBO: NO TIEDOWNS: YES


MANAGER: 208-983-4060


(2) REPEATER: ANDERSON BUTTE (97) RX FREQ: 168.6750 TX FREQ: 169.9500 (123.0)

REMARKS: ONGOING RODENT ACTIVITY ON SOUTH END OF RUNWAY. LAND RWY 36, TAKEOFF RWY 18, WITH A RIGHT TURN DOWN CROOKED CREEK. LANDING OR TAKEOFF WITH UNFAVORABLE WINDS NOT RECOMMENDED. CHECK AIRCRAFT PERFORMANCE FOR HIGH DENSITY ALTITUDE. RUNWAY MAY NOT BE VISIBLE FROM ALL PARTS OF TRAFFIC PATTERN. STEEP ENCLOSING TERRAIN. EXTENSIVE HELICOPTER ACTIVITY DURING SUMMER MONTHS. NO WINTER MAINTENANCE. RECOMMENDED FOR USE ONLY BY MOUNTAIN PROFICIENT PILOTS


DIXIE USFS

A05











REMARKS: LAND RWY 22, DEPART RWY 04. LANDING OR TAKEOFF WITH UNFAVORABLE WINDS NOT RECOMMENDED. CHECK AIRCRAFT PERFORMANCE FOR HIGH DENSITY ALTITUDES. GO AROUNDS FROM FINAL NOT POSSIBLE DUE TO HIGH TERRAIN. RECOMMENDED FOR USE BY MOUNTAIN PROFICIENT PILOTS. WILDLIFE/STOCK FREQUENTLY ON RWY. DO NOT TAXI PAST CONES MARKERS AT THE END OF RWY 04. NO WINTER MAINTENANCE.

FISH LAKE USFS


S92






CAUTION - USFS HELIPORT OPERATIONS ADJACENT TO SE END OF AIRPORT.
CAUTION - SPRINKLER HEADS MAY BE IN PLACE ON RWY 10-28. NORMALLY
LAND RWY 10, TAKEOFF RWY 28. RUNWAY MAY NOT BE VISIBLE FROM ALL PARTS
OF THE TRAFFIC PATTERN. NO WINTER MAINTENANCE.


GARDEN VALLEY






REMARKS: LAND RWY 36, TAKEOFF RWY 18. LANDING OR TAKEOFF WITH UNFAVORABLE WINDS NOT RECOMMENDED. FIRST 1/3 RWY 36 SOFT AND UNUSABLE IN SPRING. RWY 18-36 THRESHOLDS MARKED WITH ROCK. NO WINTER MAINTENANCE. WILDLIFE FREQUENTLY ON RUNWAY. CHECK AIRCRAFT PERFORMANCE FOR HIGH DENSITY ALTITUDES.

GRAHAM USFS






REMARKS: NORMALLY LAND RWY 03, TAKEOFF RWY 21. RUNWAY 03, FIRST 700' TURF, REMAINDER DIRT. RWY 03-21 EDGES AND THRESHOLDS MARKED WITH WHITE ROCK. NO WINTER MAINTENANCE. FIXED WING AND HELO FIREFIGHTING OPERATIONS POSSIBLE IN SUMMER.


MANAGER: 208-364-4330

IDAHO CITY USFS

SERVICES: FOOD & LODGING

ADJACENT AREAS, TIEDOWNS








REMARKS: RECOMMEND LAND RWY 22, TAKEOFF RWY 4. CHECK AIRCRAFT PERFORMANCE FOR HIGH DENSITY ALTITUDE. STEEP ENCLOSING TERRAIN. NO WINTER MAINTENANCE. *CAUTION*- OTHER TRAFFIC CONFINED TO SAME CANYON AREA. RECOMMEND REMAIN IN CANYON WHEN DEPARTING UP OR DOWNSTREAM. PISTOL CREEK AIRPORT LOCATED 2.5 MILES UPSTREAM.


INDIAN CREEK USFS

S81












REMARKS: NORMALLY LAND RWY 17, TAKEOFF RWY 35. LANDING OR TAKEOFF WITH UNFAVORABLE WINDS NOT RECOMMENDED. CHECK AIRCRAFT PERFORMANCE FOR HIGH DENSITY ALTITUDE. RECOMMENDED FOR USE ONLY BY MOUNTAIN PROFICIENT PILOTS. NO WINTER MAINTENANCE.


KRASSEL USFS


24K
















REMARKS: NORMALLY LAND RWY 21, TAKEOFF RWY 03. RUNWAY THRESHOLD MAY BE UNDEFINED. CAUTION: DEEP ELK WALLOW LOCATED ADJACENT TO NE END OF RWY 21. RUNWAY ELEVATION RISES TO THE SOUTHWEST. SPECIAL CONSIDERATION SHOULD BE GIVEN TO DENSITY ALTITUDE, TURBULENCE AND MOUNTAIN FLYING PROFICIENCY. NO WINTER MAINTENANCE.


MAHONEY CREEK USFS







NO-ID
















REMARKS: LAND RWY 18, TAKEOFF RWY 36. RUNWAY MAY NOT BE VISIBLE FROM ALL PARTS OF THE TRAFFIC PATTERN. FIRST 300' OF RWY 18 IS VERY ROUGH. STEEP ENCLOSING TERRAIN. RECOMMENDED USE ONLY BY MOUNTAIN PROFICIENT PILOTS. RUNWAY THRESHOLD MAY BE UNDEFINED. SELWAY LODGE PRIVATE AIRSTRIP LOCATED 1 MILE DOWNSTREAM (NORTH)

SHEARER USFS







SIMONDS

<u>NO-ID</u>









THOMAS CREEK

2U8



